

ThinkPad AC Adapter & Battery Quick Reference Chart

ThinkPad	Model Type	AC Adapter Part Number	DC Adapter Part Number	Ultrabay Battery	System Battery Part Number
240/X	2609	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	N/A	02K6580(L - wd)
365/E/ED/X/XD	2625	85G6719 - 35W (wd)	10K3820 - 72W (wd)	N/A	38H6304(N)
380 & 385/D/E/ED/XD/Z	2635	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	N/A	02K6507 (L - wd)
390/E/X	2626	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	N/A	02K6513 (L - wd)
560/E/X/Z	2640	02K6880 - 56W (wd) 02K6545 - 56W (wd) 560X/Z only for both	10K3820 - 72W (wd)	N/A	46H4206 (L - wd)
570/E	2644	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	Supports 2nd battery in UltraBase	02K6546 (L - wd)
600/E/X	2645	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	02K6504 (wd) for E/X only	12J2464 (L - wd)
770/E/ED/Z	9548/9549	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	N/A	83H6738 (L - wd)
iSeries 1200/1300	1161/1171	02K6880 - 56W (wd) 02K6545 - 56W (wd)	10K3820 - 72W (wd)	N/A	02K6680 (N - wd)
iSeries 1400/1500	2611 2621	11J8702 - 45W (wd) 02K6880 - 56W (wd)	10K3820 - 72W (wd) 10K3820 - 72W (wd)	N/A N/A	02K6576 (L - wd) 02K6603 (L - wd)
A21e	2628	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K6640 (L) - wd
A21e/A22e	2655	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	N/A	02K6743 (L) Pent. - wd 02K6742 (N) Cel. - wd
A2xm/A2xp	2628/2629	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K6640 (L) - wd
A3x/A3xp	2652/2653	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K6878 (L) - wd
Transnote	2675	02K6699 - 72W	N/A	N/A	02K6713 (L) - wd
G40/Mini-Dock G41	2388/2878	22P9150 - 120W - wd	N/A	N/A	08K8178 (L) G40 not Dock
R30 & R31	2656	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	N/A	02K6821 (L) - wd
R32 & R40	2658 2681/2722	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K7052 (L)
T2x	2647	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K6649 (L) - wd
T30	2366	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) - wd	02K7050 (L)
T4x/T4xp/R5xp/R5x R5xe *	*ALL*	02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	08K8190 (LP) *	92P1101 (L) - 6 Cell 92P1102 (L) - 9 Cell
X2x	2662	02K6699 - 72W 02K6880 - 56W (wd)	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	N/A	02K6651 (L) - wd
X30/31/32	2672/2884	02K6699 - 72W 02K6880 - 56W (wd)	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	02K6646 (L) ** - wd	92P1097 (L) - 6 Cell 02K7041 (L) - EXT - wd
X40	2371 2386	02K6699 - 72W 02K6880 - 56W (wd)	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	08K8190 (LP) ***	92P1009 (L) 4 Cell 92P1006 (L) - EXT 92P1119 (L) - 8 Cell
X41	2525/2527	02K6880 - 56W (wd) 02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	08K8190 (LP) ***	92P1119 (L) 8 Cell 92P1006 (L) EXT 92P1009 (L) 4 Cell
X41 Tablet	1866 1869	02K6880 - 56W (wd) 02K6699 - 72W	73P4485-72W AC/DC-wd 41N8460 - 90W AC/DC	08K8190 (LP) ***	73P5167 (L) 4 Cell 73P5168 (L) 8 Cell - wd 92P1006 (L) EXT
X60s, X61s X61LS	1702/7666 8748	40Y7696 - 65W 40Y7659 - 90W	40Y7630-90WAC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) ****-wd 43R9250 (LP) ****	40Y6999 (L) 4Cell Slimline 40Y7001 (L) 4Cell Enhan. 40Y7003 (L) 8 Cell 40Y7005 (L) 4 Cell Ext.

ThinkPad AC Adapter & Battery Quick Reference Chart

ThinkPad	Model Type	AC Adapter Part Number	DC Adapter Part Number	Ultrabay Battery	System Battery Part Number
X60, X61	1706 7673/7676/7675	40Y7696 - 65W 40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) ****-wd 43R9250 (LP) ****	40Y7001 (L) 4Cell Enhan. 40Y7003 (L) 8 Cell 40Y7005 (L) 4 Cell Ext.
X60 Tablet, X61 Tablet	6366/6363 7762/7767	40Y7696 - 65W 40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) ****-wd 43R9250 (LP) ****	40Y8314 (L) 4 Cell 40Y8318 (L) 8 Cell
X200 X200s	*ALL*	40Y7696 - 65W 40Y7659 - 90W	41N8460 - 90W AC/DC	43R9250 (LP) *****	43R9253 (L) 4 Cell 43R9254 (L) 6 Cell 43R9255 (L) 9 Cell
X200 Tablet	*ALL*	40Y7696 - 65W 40Y7659 - 90W	41N8460 - 90W AC/DC	43R9250 (LP) *****	43R9256 (L) 4 Cell 43R9257 (L) 8 Cell
X300 X301	6477/6478 4052	40Y7696 - 65W 40Y7659 - 90W	41N8460 - 90W AC/DC	43R1966 (L) 3 Cell	43R1965 (L) 3 Cell 43R1967 (L) 6 Cell
T60, T61(15.4",14.1"reg.) R60, R61(15.4",14.1"reg.) T500, W500, R500 SL400, SL500	*ALL*	40Y7696 - 65W 40Y7659 - 90W *Discrete graphics models require 90W adapter	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) - wd 43R9250 (LP) *Not supported on SL Series	40Y6799 (L) 6 Cell 40Y6797 (L) 9 Cell
SL300	*ALL*	40Y7696 - 65W 40Y7659 - 90W	41N8460 - 90W AC/DC	N/A	43R9252 (L) 4 Cell 40Y6799 (L) 6 Cell 40Y6797 (L) 9 Cell
R60e R61e(15.4",14.1"reg.)	*ALL*	40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	40Y6799 (L) 6 Cell 40Y6797 (L) 9 Cell
T61 (14.1" wide) R61 (14.1" wide) T400 R400	*ALL*	40Y7696 - 65W 40Y7659 - 90W *Discrete graphics models require 90W adapter	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) - wd 43R9250 (LP)	41U3196 (L) 4 Cell 41U3198 (L) 6 Cell 41U3197 (L) 7 Cell - wd 43R2499 (L) 9 Cell
Z60m/Z61m Z61e *****	2529/2531 9451/9452/0673	40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) ****-wd 43R9250 (LP) *****	40Y6795 (L) 6 Cell - wd 40Y6797 (L) 9 Cell
Z60t Z61t	2511/2513 9441/9442	40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	40Y6789 (LP) - wd 43R9250 (LP)	40Y6791 (L) 4 Cell - wd 40Y6793 (L) 7 Cell
Lenovo C100	O761	40Y7659 - 90W 40Y7696 - 65W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	40Y8313 (L) 8 Cell
Lenovo N100	O689 O768	40Y7659 - 90W 40Y7696 - 65W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	40Y8315 (L) 6 Cell 40Y8317 (L) 9 Cell
Lenovo N200 (14" wide)	O687	40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	41U5025 (L) 6 Cell 41U5026 (L) 9 Cell
Lenovo N200(15.4"wide)	O769	40Y7659 - 90W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	41U5027 (L) 9 Cell
Lenovo N500	*ALL*	41R4322 - 90W		N/A	51J0226 (L) 6 Cell
Lenovo V100	O763	40Y7659 - 90W 40Y7696 - 65W	40Y7630-90W AC/DC-wd 41N8460 - 90W AC/DC	N/A	40Y8319 (L) 3 Cell 40Y8321 (L) 6 Cell
IdeaPad S9e IdeaPad S10e	*ALL*	41R4441 - 40W	N/A	N/A	45K1274 (L) 3 Cell 45K1275 (L) 6 Cell

Legend

L - Li-Ion N - NiMH LP - Li-Polymer Wd - withdrawn HC - High Capacity EXT - Extended Life

Foot Notes

*1844 doesn't support an UltraBay battery - has a fixed drive
 **Ultrabay 2000 Battery support in X3x using X3 Media Slice only.
 ***Ultrabay Slim Battery support in X4x using X4 Media Slice only.

****Ultrabay battery supported in the X6x using the X6 Dock only.
 *****0673 doesn't support an UltraBay battery - has a fixed drive
 *****Ultrabay battery supported in the X200/s/t using the X200 Dock only

ThinkPad AC Adapter & Battery Quick Reference Chart

ThinkPad and IdeaPad 90W Slim AC/DC Combo Adapter	41N8460
Lenovo L1 Tip for Motorola a, e, i, v Series Phones	41R4309
Lenovo L2 Tip for Nokia Phones	41R4310
Lenovo L3 Tip for Audiovox, Kyocera, Motorola, Nextel, Samsung Phones	41R4311
Lenovo L4 Tip for Sony Ericsson Phones	41R4312
Lenovo L5 Tip for Samsung Phones	41R4313
Lenovo L6 Tip for Motorola i Series Phones	41R4314
Lenovo L7 Tip for Palm Pilot	41R4315
Lenovo L8 Tip for RIM BlackBerry and Select Motorola Phones	41R4316 - w/d
Lenovo L8a Tip for RIM BlackBerry and Select Motorola Phones	41R4478
Lenovo L9 Tip for Generic USB	41R4317
Lenovo L10 Tip for Apple iPod and iPhone	41R4318 - w/d
Lenovo L10a Tip for Apple iPod and iPhone 3G	41R4481
Lenovo 19V Tip for Lenovo Y Series	41R4319
Lenovo 16V Tip for ThinkPad R50, T40, X40, X40 Tablet Series	41R4343
Lenovo 20V Tip for ThinkPad R60, T60, X60, X60 Tablet, Z60 Series and Lenovo C, N, V Series	41R4344 - w/d
Lenovo 20V Tip for ThinkPad R/T/X/SL/W500 and Lenovo C/N/V series	41R4484
Lenovo Dual Charging Cable for 90W Slim AC/DC Combo Adapter	41R4345
Lenovo L11 Tip for Nokia Phones	41R4394
Lenovo L12 Tip for Sony Ericsson Phones	41R4396
Lenovo L13 Tip for LG Phones	41R4403
Lenovo L14 Tip for LG Phones	41R4406
Lenovo L15 Tip for Samsung Phones	41R4409
Lenovo L16 Tip for Samsung Phones	41R4412
Lenovo L17 Tip for Sanyo Phones	41R4415
Lenovo L1 Tip for Motorola (10-pack)	41R4460
Lenovo L2 Tip for Nokia (10-pack)	41R4461
Lenovo L4 Tip for Sony Ericsson (10-pack)	41R4462
Lenovo L5 Tip for Samsung (10-pack)	41R4463
Lenovo L8a Tip for RIM BlackBerry and Select Motorola Phones (10-pack)	41R4464
Lenovo L9 Tip for USB for Generic USB (10-pack)	41R4465
Lenovo L10a Tip for Apple iPhone 3G and iPod (10-pack)	41R4466
Lenovo L11 Tip for Nokia (10-pack)	41R4467
Lenovo L12 Tip for Sony Ericsson (10-pack)	41R4468
Lenovo Dual Charging Cable for Slim AC/DC Adapter (10-pack)	41R4469

Helpful Links

<http://www.lenovo.com/support/batteries>
<http://www.lenovo.com/support/poweradapters>
<http://www.lenovo.com/support/slimadapter>
<http://www.lenovo.com/support/slimadapertips>